

LAVORWASH
SERVICE

001 /14 HPC

ENG CIRCUIT BOARD TS2 :WIRES CONNECTIONS OF FUEL LEVEL INDICATOR
 FRA CIRCUIT BOARD TS2: FILS DE RACCORDEMENT INDICATEUR DE NIVEAU DE CARBURANT
 ITA SCHEDE ELETTRONICA TS2 : CABLAGGIO DEL SENSORE GASOLIO
 ESP CIRCUITOS TS2: CABLES CONEXIONES DE INDICADOR DEL NIVEL DE COMBUSTIBLE



ENG WIRES CONNECTION WITH MECHANICAL FUEL LEVEL INDICATORS
 FRA CABLAGE DU CAPTEUR AVEC MECANICIEN DIESEL
 ITA CABLAGGIO CON SENSORE GASOLIO MECCANICO
 ESP CABLEADO DEL SENSOR CON MECÁNICA DIESEL

ENG WIRES CONNECTION WITH CAPACITIVE FUEL LEVEL INDICATORS
 FRA RACCORDEMENT AVEC CAPTEUR DE CARBURANT CAPACITIFS
 ITA CABLAGGIO CON SENSORE GASOLIO CAPACITIVO
 ESP CABLEADO CON SENSOR CAPACITIVO COMBUSTIBLE



ENG CORRECT POSITION OF THE ELETTRICAL BRIDGE AND WIRES (MECH. INDIC.)
 FRA BONNE POSITION DU PONT ET FIL ÉLECTRIQUE (CAPTEUR MECANIQUE)
 ITA POSIZIONE CORRETTA DEL PONTE ELETTRICO E DEI FILI (SENSORE MECCANICO)
 ESP POSICIÓN CORRECTA DE LA PUENTE Y CABLES ELÉCTRICOS (SENSOR DE MECÁN.)

ENG CORRECT POSITION OF THE ELETTRICAL BRIDGE AND WIRES (CAPACITIVE INDIC.)
 FRA BONNE POSITION DU PONT ET FIL ÉLECTRIQUE (CAPTEUR CAPACITIF)
 ITA POSIZIONE CORRETTA DEL PONTE ELETTRICO E DEI FILI (SENSORE CAPACITIVO)
 ESP POSICIÓN CORRECTA DE LA PUENTE Y CABLES ELÉCTRICOS (SENSOR CAPACITIVO)

